



Signal Processing Using Digital Technology

Jeremy Barsten

Jeremy Stockwell

May 6, 2003

Advisors:

Dr. Thomas Stewart

Dr. Vinod Prasad



Digital Signal Processor

- Project Description
- Design and Simulation of VLSI Processor
- Design and Simulation of the VHDL Processor Implemented on the Xilinx FPGA Board
- FPGA Problems.




Project Description

- All purpose digital signal processor using FPGA/VHDL and ASIC/VLSI technology.
- Useable for a variety of applications:
 - Audio and Video
 - Cellular Technology
- Adapted depending on the application.




Project Description

- High-level Block Diagram:



Filter Design

- Manipulating a digital input utilizing multipliers and adders.
- Direct Form II realization of an IIR Filter:



$$W(n) = X(n) - a_1 W(n-1) - a_2 W(n-2)$$

$$Y(n) = b_0 W(n) + b_1 W(n-1) + b_2 W(n-2)$$




Signal Converters

- Each signal will be analog in nature.
- Requires an analog-to-digital converter at the input stage and a digital-to-analog converter at the output stage.
- Tried to use the 8-bit A/D and D/A converters that were part of the Xilinx FPGA Version II Board.





Adder and Multiplier

- Any basic signal processor consists of different stages of addition and multiplication.
- A n -bit by n -bit multiplication will take place and result in a $2*n$ -bit value.
- This answer will be added to previous values stored in a data register (discussed later).




Adder Cell









Adder Cell




5-Bit Ripple-Carry Adder - Logical Design




5-Bit Ripple Carry Adder - VLSI Design



5-Bit Adder Simulation – Added to 0




5-Bit Adder Simulation – Added to -1




Cellular Multiplication


- Cellular Multiplication:




Multiplier Cell - Logical Design




Multiplier Cell - VLSI Design




Multiplier Cell Simulation - Inputs



Multiplier Cell Simulation - Outputs




4-bit x 4-bit Multiplier



4-bit x 4-bit Multiplier




Multiplier Simulation – Multiplied by 1



Adder and Multiplier

- For 2's complement addition and multiplication:






2's Complement Adjustment


- Need to add circuitry to make the multiplier 2's complement ready.
- The values from the converter will always be positive but the coefficients will be negative.
- Need blocks on both inputs and the output of the multiplier.
- Special case: input of 10000 and output of 100000000.

2's Compliment Adjustment

- Basic cell for the adjustment 2's compliment circuit.



2's Compliment Adjustment






2's Complement Adjustment

- The blocks on the previous slide will be cascaded to make the adjustment block for the output adjustment circuitry.
- The select bit for the input will be the sign bit anded with the carry-out bit.
- The select bit for the output will be the same, where the sign bit will be the two input sign bits xored together.

Signed Multiplier Simulation – Multiplied by -1








Clock Cycle for Data Management

- 11 different stages that the VLSI processor must go through to complete the required multiplication and addition.
- Used 12 D-type flip-flops to create the clock cycles required.


Clock Cycle for Data Management- Logical Design




Clock Cycle for Data Management- VLSI Design




Inputs to the Clock Controller



Outputs C1-C6 from the Clock Controller



Outputs C7-C11 from the Clock Controller






Cycles for the VLSI Processor

<u>Cycle</u>	<u>Mul1</u>	<u>Mul2</u>	<u>Add1</u>	<u>Add2</u>	<u>Product</u>	<u>Sum</u>
1	a_1	$\omega(n-1)$			R_{mult}	
2			$x(n)$	R_{mult}		R_{add}
3	a_2	$\omega(n-2)$				$\omega(n)$
4			R_{add}	R_{mult}		
5	b_0	$\omega(n)$			R_{temp}	
6	b_1	$\omega(n-1)$			R_{mult}	
7			R_{temp}	R_{mult}		R_{add}
8	b_2	$\omega(n-2)$			R_{mult}	
9			R_{add}	R_{mult}		Y_{out}
10	$\omega(n-1) \rightarrow \omega(n-2)$					
11	$\omega(n) \rightarrow \omega(n-1)$					

VLSI Digital Signal Processor





VLSI Troubleshooting


- Needed to add overflow protection for the adder.
- Investigate the speed of the entire processor.



Investigation


- Behavioral v. Structural
- Ripple carry adder v. Carry look ahead adder.
- Parallel multiplier v. Serial multiplier.

Ripple Carry Adder



* 16-bit ripple carry adder will have 34 gate delays

CLA Adder



* 16-bit CLA adder will have 10 gate delays



Multiplier

- Advantages and disadvantages of using a parallel multiplier v. a serial multiplier.
- Speed v. Area



Area v. Speed

- Implemented serial and parallel multipliers in VHDL.

	Area	Delay	Area	Delay	Area	Delay
Serial Multiplier	7.14%	96.88ns	13.52%	210.8ns	24.49%	503.68ns
Parallel Multiplier	10.71%	27.41ns	28%	38.76ns	68.50%	75.12ns



Booth's Multiplier

- To increase the speed a Modified Booth's Algorithm was used
- For $(X) * (Y)$

Bit			Operation
Y_{i+1}	Y_i	Y	
0	0	0	add zero
0	0	1	add X
0	1	0	add X
0	1	1	add 2X
1	0	0	subtract 2X
1	0	1	Subtract X
1	1	0	Subtract X
1	1	1	Subtract 0



Booth's Multiplier

- For example $(X*Y) = 4 (0100) * -3(1101)$
- If it isn't an odd number of bits add a 0 to Y
- Segment multiplier (Y): 11010

1(010)

2(110)

<u>Segment #</u>	<u>bits</u>	<u>Action</u>
1	010	Add X
2	110	Subtract X



Booth's Multiplier

$$\begin{array}{r} 0100 \\ \times 1101 \\ \hline 0000100 \quad (\text{Add } X) \\ \underline{111100} \quad (\text{Sub } X) \\ 11110100 = -12 \end{array}$$


- A N-bit multiplier requires N/2 adds
- Results in a 60 ns delay for a 16 bit multiplier




Data Management

- Data Management is necessary to load the appropriate data to the multiplier and adder at the appropriate time, and to store data for later use.
- $W(n) = X(n) - a_1 W(n-1) - a_2 W(n-2)$
 $Y(n) = b_0 W(n) + b_1 W(n-1) + b_2 W(n-2)$
- To accomplish this I used 6 cycles

Data Management




$$X(n) - a_1 W(n-1)$$




$$X(n) - a_1 W(n-1) - a_2 W(n-2) = W(n)$$

Data Management






$$b_0 W(n)$$



$$b_0 W(n) + b_1 W(n-1)$$

Data Management



$$b_0W(n)+b_1W(n-1)+b_2W(n-2)=Y(n)$$



Data Management


- Three 3-input multiplexers were used to accomplish this task.

<u>Cycle</u>	<u>Mul1</u>	<u>Mul2</u>	<u>Add</u>		
000	This cycle is used to trigger the A/D convertor				
001	a1	W(n-1)	X(n)		
010	a2	W(n-2)	Temp Reg		
011	b2	W(n-2)	0		
100	b1	W(n-1)	Temp Reg		
101	b0	W(n)	Temp Reg	W(n-1) =>W(n-2)	
110	W(n) => W(n-1)				




Simulation

- Simulated DSP on Modelsim using simple 2nd order low pass filter
- Checked the results with the same filter using matlab



Simulation

<u>Matlab</u>	<u>DSP</u>
0.905	0.905
-0.7331	-0.733
0.5938	0.594
-0.481	-0.481
0.3896	0.3895
-0.3156	-0.3156
0.2556	0.2555
-0.207	-0.2071
0.1677	0.1676
-0.1358	-0.1359
0.11	0.11





Problems

- Multiplier was occasionally producing an extra sign bit
- FPGA clocks
- Impulse response degradation



Signal Processing Using Digital Technology

Jeremy Barsten

Jeremy Stockwell

May 6, 2003

Advisors:

Dr. Thomas Stewart

Dr. Vinod Prasad